ИНФЕРИТ

Те

IPMI Configuration Guide

TABLE OF CONTENTS

Introduction	
HTML5 Web GUI	5
Web GUI Overview	8
3.1 Menu bar	
3.2 Quick Button and Logged-in User	
3.3 Dashboard	9
3.4 Sensor	
3.5 System Information	
3.5.1 System Inventory	12
3.5.2 FRU Information	13
3.5.3 Power Source	14
3.6 Logs & Reports	
3.6.1 IPMI Event Log	14
3.6.2 Video Log	
3.7 Settings	
3.7.1 Data & Time	
3.7.2 External User Services	17
3.7.2.1 LDAP/E-directory Settings	
3.7.2.2 Active directory Settings	
3.7.2.3 RADIUS Settings	21
3.7.3 KVM Mouse Setting	23
3.7.4 Log Settings	24
3.7.4.1 Log Settings Policy	
3.7.5 Media Redirection Settings	25
3.7.5.1 General Settings	25
3.7.5.2 VMedia Instance Settings	26
3.7.5.3 Remote Session	27
3.7.6 Network Settings	
3.76.1 Network IP Settings	
3.7.6.2 DNS Configuration	
3.7.7 PAM Order Settings	
3.7.8 Platform Event Filter	
3.781 Event Filters	
3.7.8.2 Alert Policies	
3.7.8.3 LAN Destinations	

3.7.9 Services	38	
3.7.10 SMTP Settings	40	\setminus
3.7.11 SSL Settings	41	
3.7.11.1 View SSL certificate	41	
3.7.11.2 Generate SSL certificate	42	
3.7.11.3 Upload SSL certificate	43	
3.7.12 System Firewall	44	
3.7.12.1 General Firewall Settings	44	
3.7.12.2 IP Firewall Rules	45	
3.7.12.3 Port Firewall Rules	46	
3.7.13 User Management	47	
3.7.14 Video Recording	49	
3.7.14.1 Auto Video Settings	50	
3.7.15 Keep Share NIC Link Up	52	
3.8 Remote Control	53	
3.9 Image Redirection	53	
3.9.1 Remote Media	53	
3.10 Power Control	54	
3.11 Miscellaneous	55	
3.11.1 UID Control	56	
3.11.2 Post Snoop	56	
3.12 Maintenance	57	
3.12.1 Backup Configuration	57	
3.12.2 Restore Configuration	57	
3.12.3 Firmware Image Location	58	
3.12.4 Firmware Update	59	
3.12.5 BIOS Update	59	
3.12.6 Restore Factory Defaults		
3.12.7 Reset	61	
3.13 Sign out	61	

1. Introduction

The User Guide is for system administrators to remotely access computers with BMC (Baseboard Management Controllers) and IPMI (Intelligence Platform Management Interface). System administrators may easily monitor system conditions or manage issues of remote computers via the web-based interface, a web browser on the Internet.

Note: All screenshots in this document are provided for illustrative purpose only, and may be different from the actual product.

Terminology

Abbreviation	Definition	
AD	Active Directory	
BIOS	Basic Input Output System	
BMC	Baseboard Management Controller	
DHCP	Dynamic Host Configuration Protocol	
DIMM	Dual-Inline-Memory-Modules	
FRU	Field Replaceable Unit	
FQDN	Fully Qualified Domain Name	
IPMI	Intelligent Platform Management Interface	
КVМ	Keyboard, Video, and Mouse	
LDAP	Lightweight Directory Access Protocol	
ME	Intel Management Engine	
NCSI	Network Controller Sideband Interface	
NTP	Network Time Protocol	
PEF	Platform Event Filter	
POST	Power On Self-Test	
PSU	Power Supply Unit	
RADIUS	Remote Authentication Dial In User Service	
SEL	System Event Log	
SMTP	Simple Mail Transfer Protocol	
SNMP	Simple Network Management Protocol	
SSL	Secure Sockets Layer	
TSIG	Transaction Signature	
VLAN	Virtual Local Area Network	

2. HTML5 Web GUI

Logging in to Web using IPMI user

In order to login the IPMI, you must have a valid Username and a Password. Both fields are required.

1	ASROCKRACK	
Username		
Password		
Password	Jsername Sign me in	
Password Remember I	Jsername Sign me in sword	_
Password Remember I I forgot my pas Language	Jsername Sign me in sword	

Login Page

The default username and password are both «admin». It is recommended to change the username and password after your first login.

Username: Enter your username in this field.

Password: Enter your password in this field.

Remember Username: Check this option to remember your login credentials. **Sign me in:** After entering the required credentials, click the Sign me in to login to Web GUI.

I Forgot my Password: If you forget your password, you can generate a new one using this link. Enter the username, click on Forgot Password link. This will send the newly generated password to the configured email-ID for the user.

Language: Select the language of Web GUI, you can choose English, Traditional Chinese or Simplified Chinese.

Logging in to Web using SSL mutual authentication

You can also login to the IPMI via SSL mutual authentication without entering username/password.

Before you login as SSL mutual authentication, ensure that:

- 1. Upload CA certificate(.pem), server certificate(.pem) and server private key(.pem) to BMC
- 2. Install the client certificate(.p12) into the browser

Chrome: Using «//settings/» to open Manager certificates to import the certificate.

IE11: Using «Tools>Internet Options>Certificates» to import the certificate.

Firefox: Using «Tools > Options > Advanced > Certificates» to import the certificate.

3. Login to IPMI using the link <u>https://[IP address]:[mutual port number].</u>

Note:

- 1. The default mutual port number is 4433. You can modify it in Services page.
- 2. If you want to generate SSL certificate yourself, please follow the steps below.
- Install OpenSSL in your Linux machine.
- Generate CA certificate:
 - (1) Type openssl genrsa -out./private/ca.key 1024 to generate a private key
 - (Z) Type openssl req -new -x509 -days 365 -key./private/ca.key -out./certs/ca.crt to generate a certificate file(contain public key)
 - (3) Type cat./certs/ca.crt >./certs/ca.pem to transfers the file format to.pem.

• Generate server certificate:

- (1) Type openssl genrsa -out./private/server.key 1024 to generate a server key.
- (2) Type openssl req -new -key./private/server.key -out./certs/server.csr to generate the csr file.
- (3) Type openssl x509 -req -days 365 -in./certs/server.csr -CA./certs/ca.crt— CAkey./ private/ca.key -set_serial 01 -out./certs/server.crt to sign the file and generate a server certificate
- (4) Type cat./certs/server.crt >./certs/server.pem to transfers the file format to.pem.(5) Type cat./private/server.key >./private/server_key.pem to transfers the file format to.pem.
- Generate client certificate:
 - (1) Type openssl genrsa -out./private/client.key 1024 to generate a client key.
 - (2) Type openssl req -new -key./private/client.key -out./certs/client.csr to generate the csr file.

(3) Type openssl x509 -req -days 365 -in./certs/client.csr -CA./certs/ca.crt — CAkey./private/ca.key -set_serial 02 -out./certs/client.crt to sign the file andgenerate server certificate.

- (4) Type cat./certs/client.crt >./certs/client.pem to transfers the file format to.pem.(5) Type cat./private/client.key >>./certs/client.pem to export the file.
- Type openssl pkcs12 -export -in./certs/client.crt -out./certs/client.p12 -name «Client
 Name» inkey./private/client.key to transfer client certificate format to p12 for browser.

System Requirements

- Client machine with 8GB RAM.
- If the client machine has 4GB RAM, there will be lag in Video/keyboard/ mouse functionality.

Supported Browsers

- Chrome latest version.
- IE11 and above.
- Firefox (with limited support).

Note:

- 1. It is advisable to use Chrome or IE for H5Viewer, since Firefox has its own memory limitations.
- 2. Some icons may not appear on the IE browser screen.
- 3. Once you login to the application, it is recommended not using the following options.
- Refresh button of the browser
- Refresh menu of the browser
- Back and Forward options of the browser
- F5 on the keyboard
- Backspace on the keyboard

3. Web GUI Overview

3.1 Menu bar

The menu bar displays the following items.

- Power Status / UID Status
- Dashboard
- Sensor
- System Information
- Logs & Reports
- Settings
- Remote Control
- Image Redirection
- Power Control
- Miscellaneous
- Maintenance
- Sign out

	ASRockRack
	Host Online 🛛 UID Off
#	Dashboard
8 2	Sensor
•	System Information
<u>111</u>	Logs & Reports
•	Settings
Ļ	Remote Control
₿	Image Redirection
ወ	Power Control
≡	Miscellaneous
æ	Maintenance
•	Sign out

Menu bar

3.2 Quick Button and Logged-in User

The user information and quick buttons are located at the top right of the Web GUI.

¢ Sync 🛛 🔁 Refresh English 🗸 🛛 💄 admin 🗸

Ouick Button and User Information

Sync: Click the button to synchronize with latest chassis state.

Refresh: Click the button to reload the current page.

Language: Click the option to change the language (English, Traditional Chinese or Simplified Chinese) for Web GUI.

User Information: This option shows the logaed-in user name and privilege. Click Profile to view more information. Click the Sign out to log out of the Web GUL

3.3 Dashboard

The Dashboard displays the overall information about the status of the device.

Product Information	Servar Man	ituring.		FirmtLogs(b)
All Index District Control	-	transform.	Autog	
		4 200	3404	
innware Information		6.556	1.810	
UAL Formate Primate 12626		Av. CHUS	LTTY	99.78%
SOLFIneman Version 11.35		A ChG	1789	
Conversion 404/200		As president	1309	
subsects burners and subsects		4-400-161	1297	
		Av sizzerare	6200	
		N-MIDLAG	LEV	
estwork information news		A- CORE, PEN	0.00V	
ter salaan posturers at th		A-100,900	LMV	
ar numeric Alada Decat		A- LOUPEN	kmv.	
Nelseano Historia		N DAT	1.045	
A factored black (sec.)		4.31	8.3MV	
NI NORS 2		Au NC	LHV	
	•	A- 11P	1228/W	
		An instance	118.064	
		4- P\$42-094	100.004	
		+ Multical?	sizia	

Dashboard Page

Firmware Information

The Firmware Information displays the following information.

BMC Firmware Version: Displays the BMC firmware version of the device. BIOS Firmware Version: Displays the BIOS firmware version of the device. **ME Firmware Version:** Displays the ME (or PSP) firmware version of the device.

Microcode Version: Displays the microcode version of the device. **CPLD Version:** Displays the version of CPLD of the device.

Note:

BIOS version, ME (or PSP) version and Microcode version will be refreshed when the system POST, please restart the system if you see nothing on screen.

Network Information

The Network Information of the device with the following fields is shown here. Click **Details** to view more information.

MAC Address: Read-only field shows the MAC address of the device.

V4 Network Mode: The v4 network mode of the device can be either static or DHCP.

IPv4 Address: The IPv4 address of the device can be static or DHCP.

V6 Network Mode: The v6 network mode of the device can be either static or DHCP. **IPv6 Address:** The IPv6 address of the device can be static or DHCP.

Sensor Monitoring

Here lists all the available sensors on the device with the following information.

Status: This column displays the state of the device.

- 🕨 Normal state
- 📄 Critical State
- 🕨 Not Available

Sensor Name: Displays the name of the sensor. **Reading:** Displays the value of sensor readings.

Event Logs

Here displays a graphical representation of all events and occupied/ available space in logs. Click **Details** to view more information.

3.4 Sensor

The Sensor Readings page displays all the sensor related information. To open the Sensor Readings page, click **Sensor** from the menu. Click on any sensor to show more information about that particular sensor, including thresholds and a graphical representation of all associated events.

1050C has not in the second second		A root - Second
and the second second		6
Critical Sensors (0)		
	OUT mouthins services are overfail	
Discrete Sensor States (10)		
insur have	2.4s	
IN CHIL/RECHOX	HO HAVE C ASSAULTAN	
es cruz,hemotrur	Non-web againment	
PE CPU2_PROCHOT	No ever assertion	
** cfuz_tappyreat	No event assertion	
+> CPU_CATURE	No everture the	
THE Chapters	No ever caser to b	
S PSHLACION	No event assertion	
B PSUCStates	Hyperce Betected	
🕼 PSUCAE bet	No event popertise	
🗰 #202 Juna	Properce Betlictual	
Normal Sensors (32)		
lensor Naree	Anadag	
Ar LIDUPLH	1.04V	
A LIQUER	1.794	

Sensor Page

In this Sensor Reading page, Live readings for all the available sensors with details like Sensor Name, Status and Current Reading are shown.

Sensor detail:

The Sensor Readings page displays all the sensor related information. To open the Sensor Readings page, click Sensor from the menu. Click on any sensor to show more information about that particular sensor, including thresholds and a graphical representation of all associated events.

9.11_EAN1 Sensor Information		
	4200.00 Rpm	
oper Work-Recover salie	0.4gm	
spar Critical	il Apan	
sperfice-Oltical	il April	
we Mg-Critical	100 Hgzs	
www.concai	e spos	
and Mrs. Second Alle	il ápn	
asor Events		
lar 2014		
(D: 10 CPUS_FAIL answer of type Fast larged a larger files of the	at minution (Driving age	
40: e10:01: /ARL service of type Fair logged a Lower Mon-critical	6 - gilding Kow (200 shies ages	

Sensor detail Page

Types of the thresholds:

- Lower Non-Recoverable (LNR)
- Lower Critical (LC)
- Lower Non-Critical (LNC)
- Upper Non-Recoverable (UNR)
- Upper Critical (UC)
- Upper Non-Critical (UNC)

3.5 System Information

This group of pages allows you to view system information.

0

0

0

System Information Page

3.5.1 System Inventory

This page displays detailed information of active devices. Select a group to view more information.

Q

-

System Inventory Page

Note:

- 1. The information will be refreshed when the system POST. Please restart the system if you see nothing on screen.
- 2. The information on this page may differ by platforms, and this page may not be available for certain platforms.

3.5.2 FRU Information

This page displays the FRU information. Select a FRU Device ID from the FRU Information section to view the details of the selected device.

FRO Information Pail Notation					a
Available FBU Devices					47
TRI Device (3	a -				
HE Device Harter	845,961				
Chassis Information		Board Information		Penduct Information	
Dawn startalian yas Fernativeneer		Search information Area Farman Version.	+	Product information Area Formar Version	- F
LT lesin Date		Lingsage.	4	caultrafie	
Dates Ret Namber		Manufactane Date Time	We Fig 9 15-59-50 1417	Product#lanufactures	
Deali Seld Novber		Board Handacture	Adforkturk	Producthere	
Drighten Kidze		Accord Product Blama		Protect-Eartheanter	
		Tran of Devial Number		Productiversam	
		- Board Part Namber		Prestuct Serial Accessor	
		PRUTALIS		Auen Tag	
		Baard Gree		FRE Res ID	
				Productions	

FRU Page

Available FRU Devices

FRU device ID: Select the device ID from the drop-down list. **FRU Device Name:** The device name of the selected FRU device.

Chassis Information

- Area Format Version
- Chassis Type
- Chassis Part Number
- Chassis Serial Number
- Chassis Extra

Board Information

- Board Information Area
 Format Version
- Language
- Manufacture Date Time
- Board Manufacturer
- Board Product Name
- Board Serial Number
- Board Part Number
- FRU File ID
- Board Extra

Product Information

- Product Information Area
 Format Version
- Language
- Product Manufacturer
- Product Name
- Product Serial Number
- Product Version
- Product Serial Number
- Asset Tag
- FRU File ID
- Extra

3.5.3 Power Source

This page displays the PSU information. Please make sure that the PSU supports PMBus.

			distance - Sector Information - Prove Terr
ower Source			0
Slot 1 Status		Stot 2 Status	
Power Supply Status	Power Supply CH	Power Supply Status	Power Supply CR
AC Input Voltage	118 V	AC Imput Voltage	TRV
AC Input Current	0.76A	AC input Current	0.574
DC L2V Output Voltage	12.11 V	PC 12V Output Vortage	32.3 V
DC-12V Output Current	5.2A	OC 12V Output Current	6.4 Å
Temperature 1	25%	Temperature 1	28°C
Temperature 2	40 °C	Temperature 2	4010
fan 3	10000 RPM	Fan 3	#336 RPH
fan 2	16/A	Fan 2	84,05
BC 12v Output Power	64.01	PC 12V Dutput Power	84 W
AC Input Power	es w	ACinoutFower	- 110 W
PWS Serial Number	HOUD1515081278	PWS Getal Number	K35B1622000040

Power Source Page

Power Supply Status: Displays the PSU status is normal or not.
AC Input Voltage: Displays the input voltage of the PSU.
AC Input Current: Displays the input current of the PSU.
DC 12V Output Voltage: Displays the output voltage of the PSU. DC 12V
Output Current: Displays the output current of the PSU.
Temperature 1: Displays the temperature 1 of the PSU.
Temperature 2: Displays the temperature 2 of the PSU.
Fan 1: Displays the fan speed 1 of the PSU.
Fan 2: Displays the fan speed 2 of the PSU.
DC 12V Output Power: Displays the output power of the PSU.
PWS Serial Number: Displays the serial number of the PSU.

3.6 Logs & Reports

3.6.1 IPMI Event Log

This page displays the list of event logs occurred by the different sensors on this device. Double click on a record to see the details of that entry. You can use the sensor type or sensor name filter options to view those specific events or you can also sort the list of entries by clicking on any of the column headers.

•	A new / Hillington			(Alama internal)	MI Event Log
	0				
	(PMI Source) Log(Meaned and Me, Spage (c)		Noo by All largers		A Develop
	44		ATC THEM OUT VIEW	O Destimant	(MCTWHINE
	and the second sec	Second Types &	ferent Normal &	TRACKITE A	Contra de la
	649 GER Racord - Asserted	illost Up	281.84	10/13/2018, \$259:34	19
	Earlier to Renting Assetted	Photocol Bloker / Collegeneration	175/9X	10128/0006.3259(1)	ų.
	K.#.e.Alexified . Restorried	P-bollor	2#2,6A1188	INTRACIA, START.	U
	3189 Asserted -Restrict	Partie-	CP 3_CATERIE	1015/2018, 12HTUA	13
	Lower Herr - Maria going han - Chalan Taol	fab	Dath"out	10/15/2798.3022.25	12
	Lower Roma (Road - going tool - Antening	Fah	07/01_0444	MONTHERN REALIZED	
	Timustane Cluck Synch - Assetse	S Johnson S Velices	205	16/25/EUA 326889	k
	The year of the Refer to American	Spilan's Weekly	Ladoury	DOVATELIA ADDARS	
	Treature Incknyst Assets	Substituted	Deplaye	DUATUR POWER	E
	Tractory Dick type - Asserts	Spoteen Event	RIGS	101440018.87:54:58	1
	Pressica debuded - tearried	Prown buapts	HINAS Market	Pre-sold Tarractaling	6
	Preserve detected - Asserted	Placer Suisila	POAR IBalled	PerintTorestang	¥
	Napha Critical - ping trigh - Deatowhed	Vortage	PEOLINE	Pre-Rist Terrozationty	2
	Total (1997) and a series black (American)	Voltaix	POLICE UNV	Pre-with Transcraption	1

IPMI Event Log Page

and the second second second

Filter By Type: The category can be All Events, System Event Records, OEM Event Records, BIOS Generated Events, SMI Handler Events, System Management Software Events, System Software - OEM Events, Remote Console software Events, or Terminal Mode Remote Console software Events.

Filter By Sensor: Filtering can be done with the sensors mentioned in the list.

BMC Timezone: Displays the events with BMC UTC Offset timestamp.

Client Timezone: Displays the events with Client UTC Offset timestamp.

UTC Offset: Displays the current UTC Offset value based on which event Time Stamps will be updated.

Clear MCA Log: To delete MCA log.

Download MCA Log: To download the existing MCA log.

Clear Event Logs: To delete all the event logs.

Download Event Logs: To download all the existing Event Log records as text-file.

Download Event Logs Raw Data: To download all the existing Event Log records as hex format file.

3.6.2 Video Log

This page displays the list of video logs occurred by the different events on this device.

	osve gamer equi- 1 mer-
ideo Log at sins and sup	· Nove Tricking
	9
backs betz - instance O	
New 200	
Another Multiple Control of State of the Sta	Stat 3 Martine 🖸
0	

Video Log Page

Filter By Date: Filtering can be done by selecting Start Date and End Date.

3.7 Settings

This group of pages allows you to access various configuration settings.

ngs terlanalisterere			# n
O Lafest Yes		Contract of the sector of the	B
Hudia fedrocitor Saturgi	A Harry Harry	1E Noticide Series	Traductions The
06 	Suffe Laronge	titi Sumoga	System Fritad
1	E4 Wire Instantion	A A A A A A A A A A A A A A A A A A A	

Settings Page

3.7.1 Data & Time

This page allows administrator to set the date and time on the BMC. It can be used to configure either Date & Time or NTP (Network Time Protocol) server settings for the device.

	El Este & Trine Configure (Sale & Trine Mais a Sale Marchanes Marchanes Marchanes Marchanes Marchanes Marchanes	0		the Shire laws and		
	Sharaya Yi Hi Yamari Birondar (Hi Yamari Yanana gar Angata Saning Tha Angata Saning Tha	-				
		Date & T	ime Page			
Date & Time	: To specify the	current da	te and time	of the devic	e.	
Timezone: T and Manua exact local	ïmezone list cor l UTC offset for time.	ntains the U NTP server	ITC offset c , which can	llong with th be used to c	e locations display the	;
Primary NTI automatica	P Server: To con Illy setting the c	figure a pri late and tin	imary NTP : ne.	server to use	e when	
Secondary I automatica	NTP Server: To c Illy setting the c	configure a date and tin	secondary ne.	NTP server t	o use wher	1
Daylight Sa	ving Time: Enab	le daylight :	saving time	for the devi	ce.	
Automatic I the NTP Se	Date & Time: To a rver.	automatica	lly synchro	nize Date an	d Time witł	
3.72 Exter This page is	nal User Serv used to configu	vices ure the exte	ernal servic	e.		
	External User Services	R. Additionsy lattice	G.			

External User Services Page

3.7.2.1 LDAP/E-directory Settings

LDAP is an Internet protocol that BMC can use to authenticate users. If you have an LDAP server configured on your network, you can use it as an easy way to add, manage and authenticate web users. This is done by passing login requests to your LDAP Server.

=						OSYN	Cheven Englik-	1 atein -	
LDAP	/E-directory Settings					A room Sealing	Entered Hard Devines - 188	Widean Selver	
	annen 1. Die V. annen y Samera		Ran Leth pi						
			/E director	av Cotting	Dago				
		LDAP,	E-allector	y serrings	Puge				

General Settings: This page is used to configure LDAP/E-Directory settings.

E	Styre Children Lapon - 1 aber -	
Seneral LDAP/E-directory Settings	Room lange tensor lange (2016-being lange lang	
0		
Tradic DM/C-Greeney AntherGration		
teroptics type to Europeine SSL 🧭 Sast113		
Common Names From		
C IN ACENSIS XCON		
Server Alleress		
Ret		
380		
Red 199		
e Bruanaar na gib Varganaa Yarana		
Passward		
W Decars of allowed		
Search Rese		
r Eliminete anno 11,000		
co		
Carconfilizen file		
Cardinate File		
Private Roy		
E fam.		
Conorr	A Sattings Daga	
Genero		

Enable LDAP/E-Directory Authentication: Check the box to enable LDAP/E-Directory authentication.

Encryption Type: Select the encryption type for LDAP/E-Directory. Common Name Type: Select the Common Name Type for LDAP/E-Directory. Server Address: The IP address(IPv4 or IPv6) of LDAP/E-Directory server. Port: The port of LDA/E-Directory server.

Bind DN: The Bind DN is used during bind operation, which authenticates the client to the server.

Password: The password of LDA/E-Directory server.

Search Base: The Search base tells the LDAP server which part of the external directory tree to search. The search base may be something equivalent to the organization, group of external directory.

Attribute of User Login: To find the LDAP/E-Directory server which attribute should be used to identify the user.

CA Certificate File: To identify the certificate of the trusted CA certs. **Certificate File:** To find the client certificate filename.

Private Key: To find the client private key filename.

Role Groups: This page is used to add a new role group to the device. Alternatively, double click on a free slot to add a role group.

e Groups		d Henre Settings Foremalizer Servers (DARS-directorySettings - Role Design - Auth Dreig
	0	
aup Rater		
ng Domán		
g, the domain		
nd paramite	3	
HMMA Access		
Whadla Access		
	History /	

Role Groups Page

Group Name: Enter the name that identifies the role group.

Group Domain: Enter the Role Group Domain where the role group is located.

Group Privilege: Enter the level of privilege (User, Administrator, Operator, OEM, None) to assign to this role group.

KVM Access: Check the box to enable KVM access for the group.

VMedia Access: Check the box to enable VMedia access for the group.

3.7.2.2 Active directory Settings

Active Directory Settings

An active directory is a directory structure used on Microsoft Windows based computers and servers to store information and data about networks and domains. Active Directory allows you to configure the Active Directory Server Settings. The displayed table shows any configured Role Groups and the available slots. You can modify, add or delete role groups from here. Group domain can be the AD domain or a trusted domain. Group Name should correspond to the name of an actual AD group.

Active directory Settings Page

General Settings: This page is used to configure Active Directory general settings.

2

		feiture Chabert Legistes & south a	
	General Active Directory Settings	I free step (persistence) and applying (monitor) provides	
	Tradit kithe Britting a Kerstickien		
	General Optioned		
	Oue Damain Name		
	Density Eases offer Server Advests 1		
	Densidy (set offer Seven Address)		
	Domain Gent offer Souver Address 3		
	Genera	l Settings Page	
Enabl	e Active directory Authentica	tion: Check box to enable Active	
Direct	tory Authentication.		
5ecre	t User Name: The Username of	of the Active Directory Server.	

Secret Password: The Password of the Active Directory Server.

User Domain Name: The Domain Name for the user. E.g. MyDomain.com

Domain Controller Server Address1, Domain Controller Server Address2 & Domain

Controller Server Address3: The IP address of Active Directory server.

Role Groups: This page is used to add a new role group to the device. Alternatively, double click on a free slot to add a role group.

	Uspe Stateste Inglite 1 atel
	# Hone - Setting: Enternative Service: ActiveDirectorySetting: RoleDirugit - Biol D
0	
B	
E Swi	

Role Groups Page

Group Name: Enter the name that identifies the role group.

Group Domain: Enter the Role Group Domain where the role group is located.

Group Privilege: Enter the level of privilege (User, Administrator, Operator, OEM, None) to assign to this role group.

KVM Access: Check the box to enable KVM access for the group.

VMedia Access: Check the box to enable VMedia access for the group.

3.7.2.3 RADIUS Settings

RADIUS is a modular, high performance and feature-rich RADIUS suite including server, clients, development libraries and numerous additional RADIUS related utilities. You can set the RADIUS Authentication from here.

=	Shire Beefens tuiliste Laboure
RADIUS Settings	• more settings to more settings
Gargeral Did not Stellings	

RADIUS Settings Page

General RADIUS Settings: This page is used to configure Radius general settings.

			NATE.	enierun odnere	
meral RADIUS Settings		# top	- Antrian Enternisionelle	ings (WOLD Service) (15	····· (142121)
	0				
Drubte SADRIS Authentikation					
Server Address					
Port					
1813					
Secut					
Knate KMA Acces					
Emple round access					
	STATES OF				

General RADIUS Settings Page

Enable RADIUS Authentication: Check the box to enable Radius

authentication.

Server Address: The IP address of Radius server.

Port: The port number of Radius server.

Secret: The authentication secret of Radius server.

KVM Access: Check the box to enable KVM access for Radius authenticated users.

VMedia Access: Check the box to enable VMedia access for Radius authenticated users.

Advanced RADIUS Settings: This page is used to configure Advanced Radius authorization setting.

	Blyn Distant Fights 1 and -	
	A tree - Johny - Boneline Many - Manifestry - Manifestry	
0		
10 Sec.		

Advanced RADIUS Settings Page

Administrator: Configure Administrator with Vendor Specific Attribute in Server side.

Operator: Configure Operator with Vendor Specific Attribute in Server side. **User:** Configure User with Vendor Specific Attribute in Server side.

OEM Proprietary: Configure OEM Proprietary with Vendor Specific Attribute in Server side.

No Access: Configure No Access with Vendor Specific Attribute in Server side.

3.7.3 KVM Mouse Setting

KVM Mouse Setting Mouse Mode Configuration resultice restrictions()(rese)

The Redirection Console handles mouse emulation from local window to remote screen in either of three methods.

KVM Mouse Setting Page

Relative Positioning (Linux): Relative mode sends the calculated relative mouse position displacement to the server.

Absolute Positioning (Windows): The absolute position of the local mouse is sent to the server.

a Onital traine Lands

Other Mode (SLES-11 OS Installation): To have the calculated displacement from the local mouse in the center position sent to the server.

3.7.4 Log Settings

0

Log Settings

-

Log Settings Policy

C Line Storage Policy Clical Storage Policy

This page is used to configure the log settings.

Log Settings Page

Englitta . & indesis -

3.7.4.1 Log Settings Policy

This page is used to configure the log policy for the event log.

-

Log Settings Policy Page

Linear Storage Policy: Check the option to enable linear storage policy for the event log.

Circular Storage Policy: Check the option to enable circular storage policy for the event log.

3.7.5 Media Redirection Settings

This page is used to configure the media into BMC for redirection.



Media Redirection Settings Page

the trans & and

3.7.5.1 General Settings

This page is used to configure general media settings.

Bernets Multis Support	
Katel 12;541	
Bernel Adelmis for CO20471 mages	
the restore	
fettig sener	
0 mb 0 mb	
Out make them as	
China Sector.	
formed	
Tions of Digs for Chevy Variable Enages	
a Annual Stream	
Server All bale 14 House Insuran	
prost the management	
Fulling server	
10.00000000	
then type for Floory	
ad. 100	
Demails Kisha	
oseralise	
himsed	
The Charles	
ferrer de fine he haville frages	
Serve Tractorization	
fullile option	
spanowski	
Prest Type Technology	
all	
Persal) Koro	
Contractor	
Failured	

General Settings Page

Remote Media Support: Check the box to enable Remote Media support. **Mount CD/DVD:** Check the box to enable Mount CD/DVD support.

Server Address for CD/DVD Images: Displays the address of the server where the remote media images are stored.

Path in server: Displays the Source path to the remote media images. **Path in server:** Displays the Share Type of the remote media server either NFS or CIFS.

Domain Name: If share Type is Samba(CIFS), then enter domain name to authenticate on the server.

Username: If share Type is Samba(CIFS), then enter username to authenticate on the server.

Password: If share Type is Samba(CIFS), then enter password to authenticate on the server.

Same settings for Floppy/Harddisk Images: Enable/Disable to select same media type data configurations for all the remote media types.

Mount Floppy: Check the box to enable Mount Floppy support.

Server Address for Floppy Images: Displays the address of the server where the remote media images are stored.

Path in server: Displays the Source path to the remote media images. **Share Type for Floppy:** Displays the Share Type of the remote media server either NFS or CIFS.

Mount Harddisk: Check the box to enable Mount Harddisk support.

Server Address for Harddisk Images: Displays the address of the server where the remote media images are stored.

Path in server: Displays the Source path to the remote media images.

Share Type for Harddisk: Displays the Share Type of the remote media server either NFS or CIFS.

3.7.5.2 VMedia Instance Settings

This page is used to configure virtual media device settings.

	0
Nagyy dodur kultanow 4	
EUR? John interes.	
	B
and With Instances	
Novoge Hecks Holizata a Habits	

VMedia Instance Settings Page

Floppy device instances: The number of floppy devices supported for Virtual Media redirection.

CD/DVD device instances: The number of CD/DVD devices supported for Virtual Media redirection.

Harddisk instances: The number of harddisk devices supported for Virtual Media redirection.

Encrypt Media Redirection Packets: Check the box to enable Media Encryption support.

Power Save Mode: To enable or disable the virtual USB devices visibility in the host. If this option is enabled, Virtual media devices will be connected to the Host machine only at the instance launching KVM session. If this option is disabled, Virtual media devices will remain connected to the host machine all the time irrespective of KVM session status.

Odare Waters Dates, & state.

3.7.5.3 Remote Session

This page is used to configure remote session configuration settings.

more desared	
	Ð
and single over application	
Enables Kide Decryption	
nýbodtarg výt	
Auto-Street (s2)	
hery Craint	
3	
Net y The Internal Second)	
mature attacky GPA Server that it as, where KNM Lauration	

Remote Session Page

KVM Single Port Application: Check the box to enable single port support when using JViewer(Java KVM). On changing this configuration, KVM and VMedia Sessions will be restarted. If this support is enabled, KVM session will not use its dedicated port whereas both Web and KVM sessions will be established only via Web Port. If this support is disabled, KVM and Web sessions will use their own dedicated ports respectively.
Enable KVM Encryption: Check the box to enable KVM Encryption for the next redirection session when using JViewer(Java KVM). If KVM Encryption is enabled, the KVM session will use the Secure port.
Keyboard Language: This option is used to select the keyboard supported languages for both H5Viewer(HTML5 KVM) and JViewer(Java KVM).
Retry Count: This option is used to retry the redirection session for certain number of attempts.

Retry Time Interval(Seconds): This option is used to give time interval for each attempts.

Automatically OFF Server Monitor, When KVM Launches: Check the box to enable Automatically OFF Server Monitor, When KVM Launches.

Note: It will automatically close the existing remote redirection either KVM or Virtual media sessions on Single Port enable/Disable or KVM Encryption Enable/Disable.

3.7.6 Network Settings

This page is used to configure the network settings for the available LAN channels.

-

Network Settings Page

3.7.6.1 Network IP Settings

This page is used to configure the network IP settings.

4

and the second second second	
etaors IP Settings	
The second second	
1494 Interface	
ind states	
Concession of the local division of the loca	
C tomotos	
Transition Bills	
PURMITURE	
INCOMENT.	
Politikar	
Cambridge a	
Collinson .	
No. on a	
The Property is	
Distance and the later	
Constant and	
1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.	
tation with largeh	
tomo tomo	
NLAR W	
(#):	
0.00 Produ	
	100
	Sec. 2

Network IP Settings Page

Enable LAN: Check the box to enable the selected channel.

LAN Interface: Lists the available LAN interfaces.

MAC Address: Displays the MAC Address of the device. This is a read-only field.

Enable IPv4: Check the box to enable the IPv4 for the selected channel.

Enable IPv4 DHCP: Check the box to enable IPv4 DHCP support for the selected channel.

IPv4 Address: Specify the static IPv4 address for the selected channel.

IPv4 Subnet Mask: Specify the static IPv4 subnet mask for the selected channel.

IPv4 Default Gateway: Specify the static IPv4 default gateway for the selected channel.

Enable IPv6: Check the box to enable the IPv6 for the selected channel.

Enable IPv6 DHCP: Check the box to enable IPv6 DHCP support for the selected channel.

IPv6 Index: Specify a static IPv6 Index to be configured for the selected channel. E.g.: 0

IPv6 Address: Specify a static IPv6 address to be configured to the device for the selected channel. E.g.: 2004::2010

Subnet Prefix length: Specify the subnet prefix length for the IPv6 settings.

Default Gateway: Specify v6 default gateway for the IPv6 settings.

Enable VLAN: Check the box to enable the VLAN support for selected interface.

VLAN ID: The Identification for VLAN configuration.

VLAN Priority: The priority for VLAN configuration.

3.7.6.2 DNS Configuration

=

This page is used to manage the DNS settings.

	Ð
1000000	
2 DNS trailine	
w2ME Enabled	
loit Rame Setting	
Automatic 🕜 Manual	
test Rame	
444065099623553	
MC Registration Settings	
M: Hiteface:	
ordij	
Register met	
eglateration method:	
🕽 Nugdale 🚫 DHCP Client 7Q0H 🔃 Hostname	
SIL Configuration	
TSIG Author/Gratise Enabled	
urrent FSG Private File Info	
or Available	
tere 7582 private file	
	•
ionain Setting	
🤰 Astomatic 📃 Manual	
ionulis interface	
benefit_vit	1
omain Name Server Setting	
Automatic 🔄 Manual	
INS Interface	
Secult	1.
7. Policy Proc	

DNS Configuration Page

DNS Enabled: Check the box to enable the DNS support.

mDNS Enable: Check the box to enable the mDNS support.

Host Name Settings: Choose either Automatic or Manual settings.

Host Name: It displays host name of the device. If the Host setting is chosen as Manual, then specify the host name of the device.

BMC Interface: To register the BMC through the Interfaces.

Register BMC: To register BMC through registration method.

Registration Method: To register the BMC are through NS Update or DHCP Client FQDN or Hostname.

TSIG Authentication Enabled: Check this box to enable TSIG authentication while registering DNS via Nsupdate. Separate TSIG files can be uploaded for each LAN interface.

Current TSIG Private File: The information of Current TSIG private file along with its uploaded date/time will be displayed (read only).

New TSIG Private File: Browse and navigate to the TSIG private file, the file should be of private type.

Domain Setting: Select whether the domain interface will be configured manually or automatically.

Domain Interface: This field will be present if specify Domain Setting to Automatic, the field is used to display the domain interface of the device.

Domain Name: This field will be present if specify Domain Setting to Manual, the field is used to specify the domain name of the device.

Domain Name Server Setting: Select whether the DNS interface will be configured manually or automatically.

DNS Interface: This field will be present if specify Domain Name Server Setting to Automatic, the field is used to specify the interface to be used.

IP Priority: This field will be present if specify Domain Name Server Setting to Automatic, the field is used to select the IP Priority. If IP priority is IPv4, 2 IPv4 and 1 IPv6 DNS servers are used. If IP priority is IPv6, 1 IPv4 and 2 IPv6 DNS servers are used.

DNS Server 1, 2 & 3: This field will be present if specify Domain Name Server Setting to Manual, the field is used to specify the DNS (Domain Name System) server address to be configured for the BMC.

3.7.7 PAM Order Settings

This page is used to manage the DNS settings.

		0
EM Audit or discussion Order		
	101	
	1369	
	ACTIVE DIRECTIONY	
	8046	

PAM Order Settings Page

PAM Authentication Order: It shows the list of available PAM modules supported in BMC. Click and Drag the required PAM module to change its order.

Note:

1. It is recommended not keeping the same username for different PAM modules.

Δ

2. If Authentication fails, the reason for failure could be invalid user or invalid password.

3. If Radius Authentication fails, we can't differentiate whether it is invalid user or invalid password. So it is always treated as Invalid username error and PAM will try other Authentication Methods.

4. If AD contains secret username & password as empty, Authentication fails will be always treated as Invalid Password error. For Invalid Password error PAM will not try other Authentication Methods. So it is recommended keeping AD in the last location in PAM order.

3.7.8 Platform Event Filter

Platform Event Filters

Platform Event Filter (PEF) provides a mechanism for configuring the BMC to take selected actions on event messages that it receives or has internally generated. These actions include operations such as system power-off, system reset, as well as triggering the generation of an alert.

3.7.8.1 Event Filters

This page is used to configure Event filters. You can modify or add new event filter entry from here. By default, 15 event filter entries are configured among the 40 available slots.

ent Filt	ers						d hes Sang. Pathelian Tax. Latities	
at 1814	rfgreef (* 141 undigane)						0	
	HET ON 1 (Described white All Instance Settleter to any secondly one disct (1) is noted	►	PETP 45: 1 (Environment) Inflates AC Second S Interfactors for any second by PERP Metric (2) & Kateria	•	PETF Dr. 3 (Described) soliton AE Description solitons for any serverity intercalient (1) in eccem-	•	PETRO 4 Diminist when AE limited settlets to any security run Aller ((I) & name	
•	All Hit Spontaket when All Sectors matches by any function matches (A) Alternation	►	REFECT (Contractor) erter (All Sources) Surdicions to any security erev Mort (C) A anne	•	HER RE 7 (2000) Information and Sectors Interface for any new worky intervalment (2) (2-14 warms	►	PEF 82 (Classical) schen Af January schen för January som Hele I Sing schen tig som Aller ((), 6 roma	
•	AGE Value of generating on the AGE deforming matched as too as to prove the matched as too as to prove the	►	NUT NO. 24 JUNEAU AND A STREAM AND	•	VEF Br 18 downline) when all Sensors welling to any sensity resident (11) & some	►	PLF the siz (internet), where All Remotes an electric to any security rear alloct (SSIA) remo	
	ADT BL: 13 (Direction) Interv AD Intervention Instruction (C2) is some	►	POT ID: 34 (Discuss) setup Altification setuplistic is any server by manufactor () of the room	►	PGF (B: 25.20xebin) when eX locore weather blocky security considert 111(4) coore			

Event Filters Page

Event Filter Configuration: Click the **Event Filters** section to configure the event filters in the available slots.

	Event Filter Configuration	A new large functionality (sector function)	
	C Tradit With Plan		
	horses and a single		
	ertende 2		
	Bar 9 M		
	(m) (1)		
	Architylogiante (1)		
	3 A		
	E Augusta		
	deserved to		
	146 / ¹⁰		
	terrer (1)		
	(HE		
	menter (ga		
	and the second se		
	Sectore strength and a		
	Street hades		
	I MARTING A		
	and heat limit		
	(*************************************		
	- Albert C		
	all second se		
	Alleri X		
	and and a second se		
	treet fairs (dath faire		
	1		
	(president of Company)		
	Inter [data] Surgary [
	Devel \$100 (Ant) that		
	· · · · · · · · · · · · · · · · · · ·		
	Rest Rest Conserved		
	Dest (MG (Company)		
	(*)		
	Terret data falial haza		
	*		
	bed bds(Compet)		
	26		
	- Annual Bartes In Conception of		

Event Filters Configuration Page

Enable this filter: Check the box to enable the PEF settings.

Event Severity to trigger: Select any one of the Event severity from the list. **Power Action:** Select any one of the power action either Power down, Power reset or Power cycle from the drop-down list

Alert Policy Group Number: Select any one of the alert policy group number from the drop-down list.

Raw Data: Check the box to fill the Generator ID with raw data.

Generator ID 1: Enter the raw generator ID1 data value.

Generator ID 2: Enter the raw generator ID2 data value.

Generator Type: Choose the event generator as slave address - if event is generated from IPMB.

Slave Address/Software ID: Specify corresponding I2C slave address or system software ID.

Channel Number: Choose the particular channel number through which the event message is received over. Choose "0" if the event message is received via the system interface, primary IPMB, or internally generated by the BMC.

IPMB Device LUN: Choose the corresponding IPMB device LUN if event is generated by IPMB.

Sensor type: Select the type of sensor that will trigger the event filter action.

Sensor name: Choose the particular sensor from the sensor list.

Event Options: Choose event option to be either all events or sensor specific events.

Event Trigger: Enter the raw event/reading type value.

Event Data 1 AND Mask: Indicate wildcarded or compared bits.

Event Data 1 Compare 1 & Event Data 1 Compare 2: Indicate whether each bit position's comparison is an exact comparison or not.

Event Data 2 AND Mask: Similar to Event Data 1 AND Mask.

Event Data 2 Compare 1 & Event Data 2 Compare 2: Similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.

Event Data 3 AND Mask: Similar to Event Data 1 AND Mask.

Event Data 3 Compare 1 & Event Data 3 Compare 2: Similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.

3.7.8.2 Alert Policies

This page is used to configure the Alert Policy for the PEF configuration. You can add, delete or modify an entry in this page.

Alert Policies

-

0 Group: 3 (Distalled) Group: J. Doubled Group: 3 (Doubled!) Genungt 4 (Disushint) 4 A A Always send alert to this destruction. LAN Chaored: 1 Aways send alert to this dedination LAN Oranset: 1 Among send wert to this destination. Always seed when by this destination kAN Oximited 1 See Turb Sent You U Anter Tax P. Dett Built (Drongs 3 (Drankfed) Group & Disability Design 7 (Dealler) Grange & (Standord) 2 4 Always send afert to this doubteation LAN Channell 1 1 Hiways most alort to this destination 1,48 (France) 1 4 Aways send alert to this destination LAN Charleeh 1 epissend where he data destinution LAN (Permit 1 Save Term Seve To D Genteo Sert Totd Frengt & Thundson Group: M. (Secoleri fimage 12 (Tumbind) 0 1 0 Always send alert to this destination LAN Changed: 1 Always said aiset to this distribution Always send sliet to this deconstance Kooge used alort to this destruction LAN Grannet 1 LAN Charnel 1 AN Chinnell 3 Sere hait Devet Top 6 friend Warris See Burt Group 13 Disched tireport 14 / Joanth 41 Genuer 19-December Grant 1 (Mather) Aways send alert to this destination sale channels 1 Aways send went to the destination WAY Character 1 4 1 Always send aren to this destinution 4 Adways send alert to this destination UAN Channell, 1 4 iAi Quenda Bert Steell Sant To: 0 Agent Tax 6 Sert Intil Group: 2 (Discoled) Group: 3 (Doubled) (sease: 4 (Tradient) Grange 2 (Dependent) 4 Aways send alert to this destination. LAN Changel: 1 Always send alert to this destination (All Charnel: 1 4 Always send abert to this destination Mways send altert to this distination EAN Crumwil: 1 0 2 LAN Channel: 1 Serf To:0 Sent To: 0 Sent Tax 0 Sert Intil Course & (Discolari) Commit Disability Genuer # (Disation) Gram: # (freehlad) 1 Aways send alers to this dedisation Law Channels 1 1 1 Kiwaya savdi alam ta thin destilaanan AAN Channel: 1 Always send and to the destruction LAN characters Alternment alert suffer declination LAN Charvett 1 Sert toolt 2010112-0 Daniel Tal- II. Teris 10:0 Groups 30 (Antheld Group: 13 (IVasbio)/ Group: 12 (Puppled) Group: 13-Chebred Anagement and to the destination Always and anot to the destruction LAN Criment 1 Aways send alert to this declaration LAN Commit: 1 4 Hears and and in this dedication UAN Charmels 1 4 4 4 Gent Tono Sart To: 0 Sant Tar 6 Sert Ind Group: 14 (Dateblet) (woop: 15 (Foudard) Groups 1 (Disabled) (D-straps 2 (Transled) 4 4 4 2 Always send alert to this distingtion LAN Changet 1 Always send alart to this destination Allerand allert to this dustriation Measured alert in this destination LAN Gunnet L LAN Channel: I LAN Channel 1 Sert 10:0 Sent Tur 0 Sent Tet 0 Sett 10:0 Googt # (Resident) Geoup: 3 (Bitchled) Group: 4. Dirabiled Storg: 5-Disable/ 4 Alwars und aiet to the Alebination LAN Charnel: 1 4 4 Always send alort to this destination KAN Channels 1 4 Aways send aler) to this dedanation Always and plert to this demination LAN Gunnel 1 LAIRChantell \$ Dark TaxD Derst To: 0 Sent Ta: (Setti Tot.0 taverage it (December) twoop: 8 (Deboored) (bestend) + (besteed) usup: 20 (Includ) 0 0 0 Aways send alert to this deltavation k Mi Oranget L 2 Hways serve wert to this destination LAN Channels L Always send alertic thrudes an atom LAN Channell 1 Niveys send asks to this desirealism EAN Oceaned: 1 Low Dech. Reat Tre-6 Canal Tar d See Toil Group 11 (Disched) Group: \$2 (Diable) (holder \$3 (District) (Drough 54 (Disible)) 2 4 Abcayconed alert to this destination LAN Channel 1 Always send alert is this destination LAN Channel: 1 Always send alert to this doutination Always sense alart to this dastinistion 4 Ĺ LANCHORNER 1 LAN Charmel 1 SPIT 10:0 pent lo: 0 Sent Yes 9 Sent Imil Group: 15 (Dorden)) firmopy 8 (Dischool) (invation) \$ (Direction) Group: 3 (donable) Aways send alert to this destshation 4.44 Charves 1. 1 Alward send and joints destrution LAH Charack 1 1 Always send alect to this destination UAN Channell 1 (Oways send alert to this destinations LAN Channels 1 Serr. Turl Sent Tip 9 Sent Tru V Seet Turil Groups 4 (brazilieit) (mage 5 (Deable) (Houge & (Doubles!) George T (Massieles) 4 4 Always send alors to this destalation katerbarrow 4 4 Always send alert to this destination LAN Channell 1 Aways send also be the destread on LAN Channel: 1 Always served anent to this destination LAN Charmelli 1 Sert Intil Sent Tor D Sert Intil Sand Tar 6 George 3 (Naaddad) Group: 9 (Docming) Gerap: 18 (Decident Grange II (Dardied) 4 Always send alors to this dedocations Lab Overnell 1 Amagement alort to the distinution LAN Charnell 1 Always need start to this doctination. LAN Channell 1 4 Always send abort to this distination LAN Channell 1 4 4 SHE 10:0 3001 TC: 0 Serie Rock 2011 10:0 Group: 12 (Dischiel) Group: L1 (Doubled) Group: 14 (Inchied) Group: 15 (Dirded) 4 4 4 Always send alors to this deltabation LAM Chernells 1 Always need alert to this destination LAN Character 1 Height send digit to this destination Ability's send alert to this destination LAW Channell 1 LAN Churtels 1 Sert Total Sever Tit: 5 Sant Tec I Sent Tarill

Alert Policies Page

Dityre: Officingh Inglish- & advelor-

Alert Policies: Click the Alert Policies section to configure the alert policies in the available slots.

=				D-Fyine	Refrict	Eligish+	A ades
Alert Policies			d 119110	Serings - Plat	ere Kraut File	n - darbala	
Aiert Policies	Ð						
Policy Group Number							
1							
E suble this stort							
Delicy Action	10.0						
Always send plent to this detrinetion	•						
LAN-Charmel							
1	•						
Destination Selector							
	+						
Essent Specific Alart String							
Mort Styleg Key							
	-						
and a second sec	(Contraction)						
Read of the second seco	and the second						

Alert Policies Page

Policy Group Number: Displays the Policy number of the configuration.

Enable this alert: Check the box to enable the policy settings.

Policy Action: Choose any one of the Policy set values from the list.

LAN Channel: Choose a particular channel from the available channel list.

Destination Selector: Choose a particular destination from the configured destination list.

Event Specific Alert String: Check the box to specify event-specific Alert String.

Alert String Key: Specify which string is to be sent for this Alert Policy entry.

3.7.8.3 LAN Destinations

This page is used to configure the LAN destination of PEF configuration.

	=			The Setat trait. 1 atobs	
	LAN Destinations			• new Salay Robertson Tales. Instancias	
	Let Chamer 1 and Southeastin, 1 same true for the	CAR Charter 1.1 CAR Section 1.1 Intere rop See 16	CANCENERS 1 (AAC South and the S sector rate) facility for	LAN Eliment 1 LAN Eliment 1 Meter tud Set for	
	LANC Deserved 1 Loss transmitters to product Tage Sent Tage	(At Objects) At Objects Other true Sec Se	Mill Owenit 1 Interferences 1 Description Section	100 Sherwit L LAR Desendration & patier Fage Seek To:	
	MAD, Druwnet 1 Vich Bestrachter II Saft Your Saft Nei	(AR Dannel: 1 (AV Dannel: 1 (AV Paneration 10) (AP This Set The Set The	VAN Observed 1 Loss Dankrednet 13 Steref Text Sector Text	UNIT Means (1) UNIT Means (1) Service Service	
	An (frame) An (an entry) An (an entry) Area So Source Solution	Advertisances a Unit parameterisation Sentitian Sentitian Sentitian	Stat Classifier 1. Sector 1. Sector 1. Sector 1. Sector 1.		
		LAN Dest	inations Page		
Selec	t the LAN Chann	el: Select the L	.AN Channel nu	ımber.	
LAN I Desti	Destination Conf nations.	iguration : Selec	t any empty sl	ot to configure LA	AN
	=		201	Barr Status argan. 1 seen.	
	LAN Destination Configuration	0			
	Maria Sana Taga La Mari Marina Sana Sana Sana Sana Sana Sana Sana S				
	L	AN Destination	Configuration	Page	
LAN (only).	Channel: Display	s LAN Channel	Number for the	e selected slot (re	
(read SNMI an E-	Destination: Disp only). P Destination Add mail alert. For E ess, BMC User	lays ID for sett dress: Destinati -mail alerts, th	ing Destination ion type can be e four fields - S	e either an SNMP	Trap or

Name, Email subject and Email message needs to be filled. For SNMP Trap, only the SNMP Destination Address has to be filled.

BMC User Name: If Destination type is Email Alert, then choose the user to whom the email alert has to be sent.

Email Subject & Email Message: These fields must be configured if email alert is chosen as destination type. An email will be sent to the configured email address of the user in case of any severity events with a subject specified in subject field and will contain the message field's content as the email body. These fields are not applicable for 'AMI-Format' email users.

3.7.9 Services

This page is used to displays the basic information about services running in the BMC.

							O fave: 2 NeAwah	English-	admin .
Services								# Home - Setting	a - Sevies
									Ø
Service C	Status 🛎	intenfaces 2	Not Reserve Port #	Same Part 5	Tiesenut 4	Maabnam Sassions 2			
web	Active	bond2	81	643	1800	20		= /	
Jerem .	Active	bond0	7574	7582	1800	2		- 1	
cd.modia	Active	tiond3	5124	5124	94,05			- 🔽	
to-media	Active	DOUD	35.22	5120	165	4		- 🔽	
hd-media	Active	bend0	5121	512.7	NL/4	+		- 2	
sih	Active	1940.	NON	32	809	N/A		- 🕢	
solanti	Inactive	bone0	92223	16/5	00	16/6		- 12	

Services Page

Services: Displays service name of the selected slot (read only).

Status: Displays the current status of the service, either active or inactive state.

Interfaces: It shows the interface in which service is running.

Nonsecure Port: Displays non secure port number of the service.

Secure Port: Displays secure port number of the service.

Timeout: Displays the session timeout value of the service.

Maximum Sessions: Displays the maximum number of allowed sessions for the service.

View the active sessions: Click View icon = to view the details about the active sessions for the service.

Array were browned						-
0						Service Sessions
						Active Sector - Male
	Prisibige 8	(Xec.)9 \$	Stat Same 2	Charles 6	Section Type @	Balance (C) (C)
	Administration	192,288,36,22	adenti		And HTP25	t,

Service Sessions Page

Session ID: Displays the ID of the active sessions.

Session Type: Displays the type of the active sessions.

User ID: Displays the ID of the user.

User Name: Displays the name of the user.

Client IP: Displays the IP addresses that are already configured for the active sessions

Privilege: Displays the access privilege of the user.

Terminate Session: Click Terminate icon **o** to terminate the particular session of the service.

Edit the existing service: Click Edit icon **Z** to modify the configuration of the service.

wice Configuration			Diger Chitter Sight. 1 at	NID;+
Note the set of the se	ervice Configuration		A new - Antique - Service - Service and	tarana
week Kannel Same Same Same Same Same Same Same Same	9			
All and a set of the s	Service Name			
A kini statistication	12			
menter have	Active			
send: set accepted se second acc acc acc conduct finant: head second time finant: head second time finant: head time finant: head	Rantas Rasea			
Haranjod 6 6 6 6 6 6 6 6 6 6 6 6 6	south .			
e coarset	H HEREDON			
anagati abi abi abi abi abi abi abi ab	e			
40 Analysis	ontget			
anaport. 2015 Tomart sent sent sent tomore. It come	u9			
abl California	utaul pert	=		
E todo Thesast weat union Society.	403			
	2 Double Toremat			
1937 Arrors Backes	nood			
E tree	1800			
	ia Imure Sasciona			
	f5 tere			
	Barrow .			

Service Configuration Page

Service Name: Displays service name of the selected slot(read only). **Active:** Check the box to enable the service.

Interface Name: Choose any one of the available interfaces from the dropdown list.

Non-secure Port: Configure non secure port number for the service. **Secure Port:** Configure secure port number for the service. Mutual Port: Configure mutual port number for the service.

Enable Timeout: Check the box to enable the timeout function.

Timeout: Configure the session timeout for the service.

Maximum Sessions: Displays the maximum number of allowed sessions for the service.

3.7.10 SMTP Settings

=

This is used to configure the SMTP settings of the device.

Lab Handbas Lab Handbas Lab Handbas Lab Handbas Lab Handbas Privacy Stores Ratis Privacy Stores Ratis Privacy Ratis Privacy Stores R	0
bed0 Serdie Enal (3) Serdie Enal (3) Friewy Seree Rame Priewy Seree Rame Priewy	
Service Final 13	
Pérezy Seren Raine Pérezy Seren Raine Pérezy Seren R Pérezy Seren R Pérezy Seren R Pérezy Seren SOTE part Pérezy Seren SotE part Pérezy Seren Seren Seren Pérezy Seren SetE Seren Seren	
Phinesy Server IP Phinesy Server IP Phinesy Server SWTP Self:	
Pelmary Server IB Pelmary Server IB Pelmary Server SMIP pelm Pelmary Server SMIP server Pelmary Server Pe	
Héney SMTP Joel 23 24 40 Pethany SMTP Addresidadas Pethany SMTP Addresidadas Pethany SMTP Addresidadas Pethany SMTP Addresida	
23 Distancy Search SATP Joint 100 Perihang SATP Antibentikacijas Antimery Summer Distancy Saturation Perimang SATM SATULT Laudite	
Admary Series SUP Jok 463 Pritrary SUP Automitation Prinary Summer Prinary SUP AUTL Loadle Prinary SUP SUPILIS South	
403 Pelinang SKIP Auforetikacion Pelinang SkiP Auforetikacion Pelinang SkiP Aufort Scalable Pelinang SkiP Scalable	
Prinnery Skill Ski	
Princey Factored Princey Salescent Princey Sale Status Cauda Princey Sale Sale Sales	
Prinney Factored Prinney SkiTH SkiTLS Coulds Prinney SkiTH SkiTLS Coulds	
Prinning SM 19 65313.5 Couldin Persagraviti Statistics Southe	
Primary SM/ID STANTTLS Equition	
Secondary Sill P Septort	

SMTP Settings Page

LAN Interface: Displays the list of LAN channels available. Sender Email ID: Enter the valid Sender Email ID on the SMTP Server. Primary SMTP Support: Check the box to enable SMTP support for the BMC. Primary Server Name: Enter the Machine Name of the SMTP Server. Primary SMTP IP: Enter the IP address of the SMTP Server. Primary SMTP Port: Specify the SMTP Port.

Primary Secure SMTP Port: Specify the SMTP Secure Port.

Primary SMTP Authentication: Check the box to enable SMTP Authentication.

Primary Username: Enter the username to access SMTP Accounts. **Primary Password:** Enter the password for the SMTP User Account. **Primary SMTP SSLTLS Enable:** Check the box to enable SMTP SSLTLS protocol

Primary SMTP STARTTLS Enable: Check the box to enable SMTP STARTTLS protocol.

Upload SMTP CA Certificate File: This field will be present if enable **SMTP SSLTLS Enable** or **STARTTLS Enable**, the field is used to upload CACERT key file.

Upload SMTP Certificate File: This field will be present if enable **SMTP SSLTLS Enable** or **STARTTLS Enable**, the field is used to upload CERT key file.

Upload SMTP Private Key: This field will be present if enable **SMTP SSLTLS Enable** or **STARTTLS Enable**, the field is used to upload SMTP key file. **Secondary SMTP Support:** Check the box to enable secondary SMTP support for the BMC.

3.7.11 SSL Settings

This page is used to configure SSL certificate for the BMC.



SSL Settings Page

3.7.11.1 View SSL certificate

This page is used to view the uploaded SSL certificate in readable format.

View SSL Certificate	A firm large distance investories	
Current Contractor of Survey State Substances Substances Substances Substances Supersonal Sup		
Indu by Jonala Natar (Januar Mana, 77)		
66 San Tapaton (K) San Tapaton (K) San Tapaton (K) San Tapaton (K) San Tapaton (K) San Tapaton (K)		
oran Mar Para Halandi)) Gragi Mara Malakan Mar Mara		
NATION AND AND AND AND AND AND AND AND AND AN		
Sandri Sanar Marg Mj an Sandri Sangar Sangar Sangar Sandri Sangar Sangar Sangar Sandri Sangar Sangar Sangar		
Nazari Nazari Savatr Davinata)) Kitay Nazari, Kato Mikan (M		
Integer an articular () an Number Insidemen Number Insidemen		

View SSL certificate Page

Note: This page provides a simple method to generate SSL certificate and it is not issued by a trusted Certificate Authority, you can upload a trusted certificate by yourself, if necessary.

3.7.11.2 Generate SSL certificate

This page is used to generate the SSL certificate based on configuration details.

ř.	Objec Seatort repuis 2 alasis-
enerate SSL Certificate	
D .	
Toge datase (1)	
Therein and the	
man control (
Read of Disasters (DI)	
Sandry(3)	
Installance	
Northe Control of Cont	
Recently Second	
R. sec	

Generate SSL certificate Page

Common Name(CN): Common name for which certificate is to be generated.

Organization(O): Organization name for which the certificate is to be generated.

Organization Unit(OU): Over all organization section unit name for which certificate is to be generated.

City or Locality(L): City or Locality of the organization.

State or Province(ST): State or Province of the organization.

Country(C): Country code of the organization. Email Address: E-mail Address of the organization.

Valid for: Validity of the certificate.

Key Length: The key length bit value of the certificate.

3.7.11.3 Upload SSL certificate

This page is used to upload the certificate and private key file into the BMC.

ter Station Inght- Ladmin-

pload SSL Certificate	
	0
Darrent Der ifficate	
filed Hav 37 (0:58/6-2018	
New Cartificate	
Carlos I Private Key	
Hant Persona Gray	
🛃 tylesdex Combosis	
Ren CA Cardificato	
	To second

Upload SSL certificate Page

Current Certificate: Displays current certificate and uploaded date/time (read only).

New Certificate: Browse and navigate to the certificate file, the file should be of pem type

Current Private Key: Displays current Private key information (read only).

New Private Key: Browse and navigate to the private key file, the file should be of the type pem.

Upload CA Certificate: Check this option to upload CA Certificate file.

New CA Certificate: Browse and navigate to the CA certificate file.

3.7.12 System Firewall

Existing Firewall Settings

Ö

This page is used to configure the firewall settings. The firewall rule can be set for an IP or range of IP Addresses or Port numbers.

	=			friter Oheren ingel- A se	india -	
	System Firewall	0	o	A row - server - serve		
	General Present Settings	Presiden	Attivation			
3.712.1 0	Seneral Firewa	System Firev	wall Page			
This pag	le is used to con	figure general fi	rewall settin	gs.		
	E Concept Frequent Forthers			Sign Distant Inget-	A anto -	
	Centeral Friewall Seconds	+ Add Travel Server				

General Firewall Settings Page

Dates Later.

Existing Firewall Settings: This page is used to displays existing firewall settings.

Existing Firewall Settings Page

Add Firewall Settings: This page is used to displays add firewall settings.

)s							
		Add Firewall Settings		•		Bare	Diffugi Digita I, etain -	
<u> </u>								
	Block Al	.l: This op	Ad	dd Firewall S lock all inco	Settings Po oming IPs a	age nd Ports.		
	Flush Al 3.7.12.2 This pag	l: This opt IP Firew ge is used	ion is use all Rules to add a i	d to flush al ; new IP Addr	ll the syste ess or Ran	em firewall Ige to firew	rules. vall setting	IS.
		IP Firewall Rules		+ ADD PTAN		0 Spe	Chefran (1930) 🖡 advar-	
				IP Firewall	Rules Page	e		
	Existing	IP Rules:	This page	is used to c	displays exi	sting IP ru	les.	
		Existing IP Rules Oraceptitude Proceeding	0	4 Maga 192,0655 192,166539 Bac Book				
				Existing IP	Rules Page	e		

Add IP Rule: This page is used to displays add IP rule settings.

ir Singin (m. Kanga Kan) Al-Nanga Kari		
et hange best		P Sign (si kaupi turi
		f bene bot
		alteral .
tun -		na.

Add IP Rule Page

dies maine ineres & sint

IP Single (or) Range Start: This field is used to configure the IP address or range of IP addresses.

IP Range End: This field is used to configure the IP range end of IP addresses.

Rules: This field is used to determine the rule to Allow or Block.

3.7.12.3 Port Firewall Rules

This page is used to add a new Port or Range to firewall settings.



Add Port Rule: This page is used to displays add port rule settings.

	0
Next Grigle (w)Range Start	
Port Range Lind	
teeldge 1	
Protocol	
104	
Webseurk Type	
PvL	1
Redu	
Allow	
Rote: Foi normal usage, please DO HOT ISSCE the naming service parts. Other wis arriving services work normally.	e, we careed guarantee the

Add Port Rule Page

Port Single (or) Range Start: This field is used to configure the port number or range of port numbers.

Port Range End: This field is used to configure the port range end of port numbers. Protocol: This field is used to configure the protocol.

Network Type: This field is used to configure the network type.

Rule: This field is used to determine the rule to Allow or Block.

3.7.13 User Management

This page displays the current list of user slots for the server. You can add a new user and modify or delete the existing users.

ser Management	a design of the second s		minut	an and a second	
Advisionator Anticipation		ar 11		*	
		4	(Intelligence)	(incred)	
A (Instant)	ــــــــــــــــــــــــــــــــــــــ				
			ant Daga		

Add a new user: To add a new user, select a free section and click on the empty section.

	0
Includes.	
Constant Size	
18 laytes	-
Tunanted	
Confirm Password	
Levidie uver Accum	
Setwork Trive age	100
	1
(ustat Polishigar	
	it.
WWW doitions	
ENG-dia torong	
unal format	
(real I)	
Calculuty SSH Key	
hethaniste	
lykood Sil+Kny	-

Add User Page

Username: Enter the name of the user.

Password Size: Either 16 Bytes or 20 Bytes password size can be chosen.

Password: Enter the password of the user.

Confirm Password: Confirm the password.

Enable User Access: Enabling user access will intern assign the IPMI messaging privilege to user.

Network Privilege: Select the network privileges assigned to the user.

Serial Privilege: Select the serial privileges assigned to the user.

KVM Access: Assign the KVM privilege for the user.

VMedia Access: Assign the VMedia privilege for the user.

Note: Both KVM and VMedia privilege will enable(disable) automatic when Network Privilege is administrator(other).

Email Format: Specify the format for the email. Two types of formats are available.

AMI-Format: The subject of this mail format is 'Alert from (your Host name)'. The mail content shows sensor information, ex: Sensor type and Description.

Fixed-Subject Format: This format displays the message according to user's setting. You must set the subject and message for email alert.

Email ID: Enter the email ID of the user. If the user forgets the password, the new password will be mailed to the configured email address.

Existing SSH Key: Displays the uploaded SSH key information(read only). **Upload SSH Key:** Upload the public SSH key file.

Modify user: To modify the existing user, click on the active user tab.

				Disync - 2 Referiti	Engint+ 1 atestr+	
1	User Management Configuration			# none - letting - lite managemen	() the Resignment Configuration	
		0				
	Thomas					
	attro					
	Charge Present					\sim
	Provent Sta					
	36 byter	1				
	Painword					
	Canthornhouward					
	Emple user Acrest					
	Network Division					
	Aprivation					
	Serial Divilege					
	None					
	MAR ACTION					
	VH uffici decima					\sim
	Frank Dermal					_
	ABG-Parriet	E				
	Sector Sector	103				
	Contra Co					
	Existing City Rev					
	Text Ayalable					$\langle \cdot \rangle$
	Upload \$5446ey					\sim
		b				
	There	10 CM				
		Modify	Isor Pago			
		would y c	iser Puge			
.7.1	4 Video Recording					
		, , ,				
his	s page is used to conf	igure video re	cording setting	gs.		
18				O Brie 22 Robert	Inglith- & adition-	
						\sim
	lideo Recording				weet - Belings - Weethounding	
	Auto Sideo Settinan					
	and the second					$\langle \cdot \rangle$
						$\langle \rangle$
						\sim
		Video Deee	ording Daga			
		video Hecc	nuing Page			
						10

3.7.14.1 Auto Video Settings

This page is used to configure auto video recording settings.

=		OSync O'Befunli English - L admin	647
Auto Video Settings		dinare Settings Volcolenisting and volume	-
			

Auto Video Settings Page

Video Trigger Settings: This page is used to configure the events that will trigger auto video recording function of the KVM server.

Trigger Settings	# None Lettings fides Receiving Auto Whis Settings	(maxing
1981 Section 85		
0		
ritical Events (Temperature/Weltage)		
on Critical Events (Temperature/Voltage)		
os Mecoverable Events ('emperature/Nottage)		
er state changed tiernts		
ratching Time: Essetz		
tantils Drawer Con Twenths		
satisfs Power Off Events		
Nacials Reserv Controls		
NC Reset Events		
and and Time Event		
a deal decomposition		

Video Trigger Settings Page

Critical Events (Temperature/Voltage): Trigger the recording by the critical events for Temperature/Voltage sensor.

Non Critical Events (Temperature/Voltage): Trigger the recording by the noncritical events for Temperature/Voltage sensor.

Non Recoverable Events (Temperature/Voltage): Trigger the recording by the non-recoverable events for Temperature/Voltage sensor.

Fan state changed Events: Trigger the recording by all fan sensor events **Watchdog Timer Events:** Trigger the recording when watchdog timer be triggered.

Chassis Power On Events: Trigger the recording by system power on events (DC on).

Chassis Power Off Events: Trigger the recording by system power off events (DC off).

Chassis Reset Events: Trigger the recording by system reset events.

LPC Reset Events: Trigger the recording by Host LPCRESET event.

Date and Time Event: Trigger the recording by specific date and time. **Pre-Event Video Recording:** Select Crash Reset either **Pre-crash** or **Pre-reset**.

Video Remote Storage: This page is used to configure the remote storage path.

O Got: Charter Light- Lares

	0
Recent Alloc to their allo terror	
Kalka a farai	
3	
Radia to Datalia (Sec)	
28	
Paulinean Star (Md)	
*	
Marten Address	
Same Participation	
fadicki sever	
ag middel anno	
phase type	
alastige No cos	
	12 Aug

Video Remote Storage Page

Record Video to Remote Server: Check the box to enable remote video support. If remote video support is enabled, then the video files will be stored in remote path.

Maximum Dumps: Enter maximum dumps of the video.

Maximum Duration(Sec): Enter maximum duration of the video.

Maximum Size(MB): Enter maximum size of the video.

Server Address: Specify server address of the server.

Path in Server: Select the **Share Type** (NFS/CIFS). If the selected share type is (CIFS), enter the **User Name**, **Password** and **Domain Name** in the respective fields.

Pre-Event Video Recordings: This page used to configure the Pre-Event video recording configurations.

News - Selarge - Value Recording - Auto Natio Selarge - Yes Court Value Recording

Pre-Event Video Recordings

	Ø
The page used to configure the the Event store recording configurations free fresh in correctly the block. To enable the Pre-Event while recording in <u>Sciences Configuration</u> rides.	ono recording to page and trigger that
video quality	
Mrg Ltw	-
Compression Stude	
mp	
Transes Per Soland	
1	•
Video Duration	
39	-
	The Save

Pre-Event Video Recording Page

Video Quality: To set video quality, select ranges from the drop-down list.

Compression Mode: To set compression mode, select modes from the dropdown list.

Frames Per Second: To set number of frames per second, select frames/sec (1-4) from the drop-down list.

Video Duration: To set duration of video, select second (10-60) from the drop-down list.

3.7.1.5 Keep Share NIC Link Up

This page is used to configure share NIC(NCSI) PHY link up setting.

Keep Share NIC Link Up	¢
C Indde	
	21/idea

Keep Share NIC Link Up Page

Enable: Check the box to enable Keep Share NIC Link Up, share NIC PHY will keep link up, and it could avoid share NIC disconnection while system reset.

3.8 Remote Control

This page is used to launch the remote console redirection.



3.9.1 Remote Media

This page is used to configure the remote images into BMC for redirection.

Royan Caglant + A adams +

these - reached active - ferring that

					Q Retrest image List
Madia Type	Media Instance	tra agei titartae	Badfeettin Status	Committed Service Service	
CEVDA0	3	These survey etc. +	*	5414	• •
CE/DVD	181	thei server 4. •		404	P . A
68,510	2	ind server 6. •		74(A	• •
60,090	3	thei tarren 4. +		N/A	b A
Prest	4			Net94	5 A
Property				nja	۰. ۵
Presse.	3			MA:	+ . A
Hungs	1		4	7494	F &
Hartschilt			3	541A	+ a
Hardshik	1			A404	+ . a
Hartona	3		*	NA.	 a
Hardelsk	3			N(3-	+

Remote Media Page

Media Type: Displays type of Media such as CD/DVD, Floppy and Hard-disk. Media Instance: Displays total media instance count.

Image Name: Displays the default recovery image name on the server.

Status: Displays the status of the media.

Session Index: Displays Media Server Session Index.

Start/Stop Redirection: To start or stop media redirection.

Pause: To pause the media redirection.

Refresh Image List: To get latest Image lists from the Remote Storage.

Note: To configure the image, you need to enable Remote Media support first.

3.10 Power Control

Remote Media :

This page is used to view and control the power of the server.

Power Actions	e
Hist is currently off	
PowerOff	
Power On	
PowerCycle	
Hard Roset	
ACPI Stutidizen/Soft Stutilisen)	
	O metanal Action

		5 Sync	O Adresh	English +	1 ada
wer Control as southener				# 19494	- Cana
ower Actions	Ø				
int is convertigat					
Preprint					
PawerOn					
Pewet Cycle					
Hard Roset					
ACPI Stutilisen/Seft Stutilisen)					
	O meture extrem				

Power Control Page

Power Off: Select this option to immediately power off the server.

Power On: Select this option to power on the server.

Power Cycle: Select this option to first power off, and then reboot the system (cold boot).

Hard Reset: Select this option to reboot the system without powering off (warm boot).

ACPI Shutdown(Soft Shutdown): Select this option to initiate operating system shutdown prior to the shutdown.

3.11 Miscellaneous

This page is used to configure miscellaneous settings.

=		Goyac Dhefrah Ergish - 🛦 admin -
Miscellaneous		# Horse - Hinstherene
0	0	
	Miscellaneous Page	
	E Miscellaneous	Tiscellaneous

3.11.1 UID Control

This page is used to control the UID of the chassis.

Control manufactory				et Hote - Hazzlandou - Ultria
D ACTOR J Tuns 09 TungasanyOn Tuns 09	C Pergana kelak			
	UID Cor	ntrol Page		
rn On: Select this o _l	otion to turn on	UID.		
mporary On: Select	this option to t	emporary turr	on UID.(15 :	sec blink)
n Off: Salaat this a	ntion to turn of	. J	,	
IT OTT. Delect LINS O				
I.2 Post Snoop	icplay the lact [
is page is used to a	isplay the last f		505.	
			60	yne Offichaal Digizli- 🛓 admin Antone Maailanaana (hati
rt 80h				
veraste ab				
	Post Sr	noop Page		

3.12 Maintenance

This page is used to do maintenance tasks on the device.



3.12.2 Restore Configuration

This page is used to restore the configuration files from the client system to the BMC.

Koyne Ditafiesh English- & satesha -

Restore Configuration

	6
ConfigFile	
	E2 Uption

Restore Configuration Page

Config File: This option is used to select the file which was backup earlier. **Upload:** To upload the backup file to restore the backup files.

3.12.3 Firmware Image Location

This page is used to configure firmware image into the BMC.

	0
Image Location Tube	
Web Upload during Tash	
O TED Server	
TITP Server Address	
Bugated, STITP in channe	
TFTF lenge Starse	
Negated, PTFTF tachosts	
TETP Retry Count	
8	

Firmware Image Location Page

Web Upload during flash: Select the option to transfer the firmware image into the BMC via HTTP/HTTPS.

TFTP Server: Select the option to transfer the firmware image into the BMC via TFTP.

TFTP Server Address: This field will be present if enable **TFTP Server**, the field is used to configure the address of TFTP server.

TFTP Image Name: This field will be present if enable **TFTP Server**, the field is used to configure full source path with filename of TFTP server.

TFTP Retry Count: This field will be present if enable **TFTP Server**, the field is used to configure the number of times to be retried in case a transfer failure occurs.

3.12.4 Firmware Update

This page is used to update BMC firmware.

	- 6
The protocol of exception to the soft for Protocol entry Tallactic army the and sins a follows. We soft protocol to solve an application of other for examples.	
Promise of Configuration	
Presente Relative Settings	
Present fast binnet	
Infand, Pharamanan Menger	
12	

Firmware Update Page

Preserve all Configuration: To preserve all configuration.
Preserve Network Settings: To preserve network settings.
Preserve User Account: To preserve user accounts.
Select Firmware Image: To Select the firmware image to be uploaded.
Start Firmware Update: To Start the firmware update.

3.12.5 BIOS Update

This page is used to update BIOS firmware.

=	Caye Deabast signs & abox -
BIOS Update	A New Research Electron
0	
i oggevite produ ef tre vlytt. Nama anlætt 1925 - magn und grænt 1924 av 1930 avjatent för start tilt v 1931 apräkte provinkan.	
Configuration	
Preserve ROS und ga alian	
Option	
Immediatory decidence or vector facilities	
Saind BDD map	
32. ×6493 ·	
E THE WARMAN TO	

BIOS Update Page

Preserve BIOS configuration: To preserve BIOS configuration.

Immediately shutdown server to flash BIOS: To shutdown server immediately to flash BIOS.

Start Firmware Update: To Start the BIOS update.

3.12.6 Restore Factory Defaults

This page is used to restore the factory defaults of the device firmware.

-				wayne aurereite Ergiet-	annet -
Restore Factory Defaults				H Human - Hardatana - Hadave	istery Debuchs
All firmware settings will be restored to factory defailts.					
	Construction of the Association				
	Restore Fac	tory Defaults F	Page		
estore Factory De	efaults: Click the	button to rest	ore configu	uration to	
	curigs, the rottow	ing sectings wi			
SEL					
IPMI					
Network					
NTP					
SSH					
KVM					
Authentication					
Web					

60

3.12.7 Reset

Reset

This page is used to reset BMC device.

Reset Page

Reset: Click the button to reset the device.

3.13 Sign out

Click **Sign Out** to perform log out from the Web GUI. A Warning message will be prompted you to proceed further, click **OK** to log out else **Cancel** to retain the Web GUI.



inferit.com | info@inferit.com Россия, 141190 г. Фрязино, Заводской проезд 3к1